

IV. MAINTENANCE

The frequency of the following maintenance checks depends on the amount and kind of materials being sprayed. Under all circumstances, however, these checks should be made at regular intervals to reduce fire hazards, to maintain the efficiency of the booth, to prevent freshly painted objects from becoming blemished and to hinder rust of the booth.

1. Daily or when overspray accumulates – remove the overspray and coating from the booth interior, operator's floor area, baffles, fan and exhaust piping. Use a non-ferrous, non-sparking scraper to eliminate any possibilities of igniting combustible material. Do not allow overspray to accumulate, presenting a fire hazard. Do not leave piles of paint sweepings in the booth.
2. When overspray accumulates, remove exhaust unit blade and clean
3. Check belt tension on exhaust unit periodically. Bearing in fan and motor may wear unnecessarily when belts are too tight.
4. Replace filters as needed.