


DETAIL XI
PERSONNEL DOOR INSTALLATION

NOTES

- ASSEMBLE DOOR AND LATCH WITH TEK SCREWS.
- ADJUST LOCATION OF LATCH AS NEEDED FOR SMOOTH OPERATION.
- IF LATCH MUST BE MOVED OUTWARD FROM THE BRACKET, SHIMS MAY BE USED AND 1/4 BOLTS USED FOR MOUNTING.
- ADJUST TENSION IN THE LATCH USING THE TENSION SCREW AS NEEDED FOR SMOOTH OPERATION.
- APPLY THIN FILM OF GREASE IF NEEDED FOR SMOOTH OPERATION.

4x3 BRACKET
ATTACH WITH TEK SCREWS
FROM INSIDE BOOTH



DETAIL XII
W-156 BRIXTON LATCH INSTALLATION



Greensboro, NC 27405
Ph - 1-800-451-2425

title		GENERAL INSTRUCTIONS	
part no		DOOR DETAILS XI & XII	
order no		XXXX	
drawn by	MBOWLES	date	10-24-03
file name	XXXX	rev	A