



DETAIL II - JOINING PANELS AT CORNER PLENUM


STARTING POINT TYPICAL FOR CF-1000, SD-1000, PRF-1000,
RFCF-1000, RFSD-1000, IPW-1000



DETAIL III - PANEL JOINT DETAIL TYPICAL FOR WALL & CEILING PANELS



DETAIL IV - MOUNTING PANEL TO FLOOR



DETAIL I - BUILT-UP ROOF PENETRATION



Greensboro, NC 27405
Ph - 1-800-451-2425

title	DETAILS TO ASSEMBLE ST 1 OF 2	
part no	DETAILS I - IV	
order no	-	
drawn by	MBOWLES	date 10-15-03
file name	XXXX	rev A